

Care Instructions

The fabric cover is treated with UV protection. However, it is very important to further protect your fabric cover with a high quality UV treatment *every 6-8 months*.

Speed-Way Shelters recommends using the following products to preserve the life of your shelter!



Ray Bloc UV Fabric Spray Sun Protector,
Protects fabric from harmful UVA & UVB rays

How to Apply

1. Start with thoroughly clean and dry fabric.
2. Apply outdoors or in well-ventilated area
3. Spray until Shelter is evenly wet but do not over apply
4. Use sponge damp with Ray Bloc and gently wipe any large drops on Shelter
5. Do not allow large drops or puddles to dry
6. Allow Shelter fabric to completely dry before use, preferably in full sunlight.



Aqua Armor Fabric Waterproof treatment,
Repels Water, Prevents Stains

How to Apply

1. Start with a thoroughly cleaned and dry fabric
2. Apply outdoors or in well-ventilated area
3. Spray until Shelter is evenly wet but do not over apply
4. Use sponge with Aqua Armor and gently wipe any large drops.
5. Do not allow drops or puddles to dry
6. Allow Shelter fabric to completely dry preferably in full sunlight

