



Speedway Shelters Wood Base Foundation Assembly Instructions

Materials and tools needed:



Power Drill & 2" woodscrews (28 ea.)



1.5 inch bolts & nuts (6) & washers (12)



3/4 inch plywood & 2x4 supports



Separate 2x4s approx.. 20" apart



Attach 2x4s to plywood using 2" screws



Finished base - for best results apply a standard patio or deck waterproofing agent / sealer



Locate two anchor holes on both sides of frame assembly. Mark and drill holes.



Secure game to plywood using 1.5" bolts, washers, and nuts



Use same 1.5" bolts, nuts, and washers to secure anchor plate (2 holes)



Add a Speedway Shelters Diamond Tough rubber floor mat for extra protection from moisture and dust



Keep water and dirt away, providing a dry and clean interior



Completed base for your Speedway Shelter!

Note: check the dimensions of your specific model then add *at least* two inches to the length and width to calculate the size of plywood you need to build your base